

Hercular® & Gate Latch Lock - Installation Template

1. Place template on high edges of door bevel

4. Mark center for a $2\frac{1}{8}$ " hole

$1\frac{3}{4}$ "
(44mm) $1\frac{3}{8}$ "
(35mm)

3. Mark at center of door thickness

For Standard bolt drill:
1" hole

For Drive-in bolt drill:
 $1\frac{1}{8}$ " hole

2. Fold here on edge of door

$2\frac{3}{8}$ "

$2\frac{3}{4}$ "



MUL-T-LOCK®

Visit our website for more information

MUL-T-LOCK-ONLINE.COM

The most trusted source of MUL-T-LOCK products in USA